


Chenille Mix Type *Multi-Head* SWF/CA-series



SELECTION OF EMBROIDERY METHOD

Either Chain Stitch or Loop Stitch may be selected for embroidery.

NEEDLE BAR HEIGHT SETTING

The height of the needle bar may be changed by 0.3mm per step from Step 1 through Step 10.

CHENILLE EMBROIDERY TRIMMING

Either Chain Stitch or Loop Stitch can be selected for trimming.

EXPANDED MEMORY SIZE

The machine can store a maximum of 100 designs. The basic memory size is 2 million stitches.

MIRROR IMAGE CONVERSION AND DESIGN DIRECTION

You can turn the from 0° to 359° in the increments of 1° and also reverse the design in the X direction (mirror image).

ENLARGING AND REDUCTION DESIGN

You can reduce or enlarge the embroidery design in size from 50% to 200% by 1% along the X and Y axis.

AUTOMATIC SELECTION OF NEEDLE BAR

You can select the order of the needle bars up to the 99th.

GENERAL REPETITION WORK

The same design can be repeated up to 99 times along the X and Y axis.

SPECIAL REPETITION WORK

Several designs can be repeated up to 63 times at different angles and directions.

AUTOMATIC OFFSET

The frame automatically returns to the offset point when the embroidery is finished to make it easier for you to switch the frames. You can select AUTOMATIC OFFSET at PARAMETER SELECT MODE to move the frame automatically to the desired point, making it easier to do appliqués and to switch the frames.

❑ **MANUAL OFFSET**

You can manually move the frame to the pre-selected point to do appliqués or change the frames during embroidery work. The frame can be moved back to its original place by simply pressing the right buttons.

❑ **ORIGIN RETURN**

The frame can be moved back to the start point of the design during the embroidery work.

❑ **FLOAT STITCH FUNCTION**

The frame and the needle bar can move back and forth by the units of 1, 100, 1000, and 10000 stitches and by color without stitching.

❑ **FRAME BACKWARD**

When the thread breaks or runs out of track, you can move the needle bar back to the starting point of the design in the units of one to ten stitches.

❑ **AUTOMATIC TRIMMING**

The automatic trimming function, determined by the design and the machine set-up, enhances work productivity and quality of the finished product.

❑ **EDIT FUNCTION**

You can delete, change, or insert stitch data and function codes (jump, finish, trimming).

❑ **INDIVIDUAL HEAD OPERATION**

You can work on the specific head with a broken thread with the remaining heads left as they are.